



EgRO NEXT

Daily Coffee Cleaning



On the upper right corner of main screen, tap the Cleaning and Settings icon in the top right corner.



Select the Coffee cleaning.



Follow on-screen instructions. Remove the coffee grounds bin. Empty the bin, wipe clean, and replace in the machine.



Insert 1 Egro Coffee Machine Cleaning tablet into the chute on the top of the machine. Continue following on-screen instructions.

Note: For NEXT Touch Coffee 4 Hopper models, the chute is located on top of the hoppers in the center.



Caution: The machine will dispense HOT water from the drink spout.

When the cleaning is done, clean the drip tray with clean wet towel. The machine is now ready for use.



DO NOT SHUT THE MACHINE OFF DURING CLEANING!

It will cause the machine to become disabled and your warranty may be voided.

Shutting off the machine will NOT reset the cleaning counter. The only way to unblock a machine that has been blocked due to lack of cleaning is to perform the complete daily cleaning.



Cleaning Product Re-Order Information

To re-order the Egro Coffee Machine Cleaning Tablets, please send your orders to: orders@ranciliogroupna.com

Egro Coffee Machine Cleaning Tablets
Product # 69000427

We offer an Auto-Ship Cleaning Supplies Program to automatically ship cleaning products to you. Call (630) 914-7900 to learn more about our program.