

Egro One

Daily Steam Wand Cleaning



1 Prepare solution by combining an Egro Milk System Tablet with 16 oz of water (or until steam tip is fully submerged).



2 Activate the steam wand until the solution is heated and allow the wand to soak in the solution for 10 minutes.



3 Dispose of the cleaning solution and refill with fresh water. Activate the steam wand until the water is heated.



4 Dispose of the water and wipe the steam wand with a clean towel.

*For iSteam wands, unscrew the nozzle and clean



Cleaning Product Re-Order Information

To re-order the Egro Milk System Cleaning Tablets, please send your orders to: orders@ranciliogroupna.com

Egro Milk System Cleaning Tablets

Product # 69000426

We offer an Auto-Ship Cleaning Supplies Program to automatically ship cleaning products to you. Call (630) 914-7900 to learn more about our program.